

Bio-oil ≠ Bio-oil - Major differences in properties and use of fast pyrolysis bio-oil compared to fossil fuels and other bio-oils

Anja Oasmaa¹, Dietrich Meier², Douglas C. Elliott³, Anthony V. Bridgwater⁴,
Fernando Preto⁵, Bert van de Beld⁶

1. VTT Technical Research Centre of Finland, Espoo, Finland

2. Johann Heinrich von Thünen-Institute (vTI), Institute of Wood Technology and Wood Biology (HTB), Hamburg,
Germany

3. Pacific Northwest National Laboratory (PNNL), Richland, Washington 99354, United States

4. Aston University, Birmingham, U.K

5. CanmetENERGY, Ottawa, Ontario, Canada


6. BTG, Enschede, The Netherlands

Contents

- ▼ Fast pyrolysis of biomass
- ▼ Chemical composition of fast pyrolysis bio-oils
- ▼ Fuel oil analyses
- ▼ Behaviour
- ▼ Comparison to other bio-fuels
- ▼ Conclusions

Fast pyrolysis of biomass

- ▼ Rapid (1-2 s) thermal (about 500 °C) degradation of biomass under inert atmosphere into bio-oil as main product and into side-products gases, and char
- ▼ Slow pyrolysis (long residence time) will produce more char, gas, and water with less organic and the condensates will be in two phases



Chemical composition of fast pyrolysis bio-oils

Hundreds of various compounds main groups being:

4 – 6 wt-% carboxylic acids

15 – 20 wt-% aldehydes, ketones, furans, pyrans, monomeric phenols, etc.

25 – 35 wt-% carbohydrates, “sugars”

20 – 30 wt-% water

20 – 25 wt-% pyrolytic lignin, extractives, solids (incl. ash), polymerisation products



→ ***Chemical composition determines physical properties***

Energy and fuels, 2003, vol. 17, 2, ss. 433 – 443

Energy Fuels, 2008, vol. 22, 6, ss. 4245 – 4248

Acids in fast pyrolysis bio-oil

COMPOSITION


2 - 6 wt-% acetic acid
 < 2 wt-% formic acid
 < 1 wt-% glycolic acid
 < 1 wt-% propionic acid
 < 1 wt-% lactic acid
 traces of other acids

ANALYSIS

Capillary Electro Phoresis (CE)
 Total Acid Number (TAN) or pH

EFFECT

Material corrosion



acid (wt %)	storage time at room temperature (months)			stability test (80 °C, 24 h)
	0	3	6	
acetic	2.2	2.5	2.5	2.5
glycolic	0.4	0.5	0.5	0.5
formic	1.2	1.4	1.3	1.3
total	3.8	4.4	4.3	4.3
TAN	70	73	71	74

Aldehydes and ketones

COMPOSITION

5 – 10 wt-%	hydroxyacetaldehyde
2 – 3 wt-%	hydroxypropanone
< 5 wt-%	other aldehydes and ketones
3 – 4 wt-%	furans, pyrans
2 – 5 wt-%	monomeric phenols

REACTIONS IN OIL


Gradual decrease in carbonyl compounds during storage

ANALYSIS

Total amount by solvent fractionation
 Compound identification by GC-FID, GC-MSD
 Carbonyl titration

EFFECT

Instability



“Sugars”

COMPOSITION

3 – 6 wt-% levoglucosan

< 1 wt-% cellobiosane, cellotriosane

Hydroxy acids

Anhydrosugar oligomers

Totally 25 – 35 wt%

ANALYSIS

Amount by solvent extraction as ether-insolubles of water soluble fraction

Amount by BRIX based on density

Compounds by HPLC or GC-MSD with derivatisation or by LC-MS

EFFECT

Stickyness

Instability

Water-insoluble fraction

R. Bayerbach, D. Meier/J. Anal. Appl. Pyrolysis 85 (2009) 98–107

COMPOSITION

15 - 20 wt-% degraded lignin

< 1 wt-% solids

1 – 5 wt-% extractives

Polymerisation products in aged liquids

ANALYSIS


Water extraction

Increase in molecular weight by GPC

EFFECT


High non-volatile fraction

High viscosity



Stability

- ▼ Not as stable as conventional petroleum fuels
- ▼ The instability can be observed as increased viscosity over time, particularly when heated
- ▼ Major changes in ageing happens in carbonyl and water insoluble fractions the changes in these product groups can be used as stability indicators
 - The changes in carbonyls can be measured by GC analyzing aldehydes and ketones, by carbonyl titration, or by FTIR
 - The changes in water-insolubles can be determined as changes in viscosity or in molecular weight
 - The change in carbonyl content correlates with the change in viscosity



Diebold, J.P. A review of the chemical and physical mechanisms of the storage stability of fast pyrolysis bio-oils. In: *Fast Pyrolysis of Biomass: A Handbook*, Vol. 2., Bridgwater, A.V. (Ed.), CPL Press, Newbury, UK, 2002, 424 p.

Scholze B. 2002. Long-term Stability, Catalytic Upgrading, and Application of Pyrolysis Oils -Improving the Properties of a Potential Substitute for Fossil Fuels. Dissertation zur Erlangung des Doktorgrades im Fachbereich Chemie der Universität Hamburg vorgelegt von Britta Scholze aus Hamburg.

Oasmaa, A. 2003. Fuel oil quality properties of wood-based pyrolysis liquids. Academic dissertation. Jyväskylä. Department of Chemistry, University of Jyväskylä. 32 p. + app. 251 p.. Research Report Series, Report 99. Doctoral thesis

Oasmaa, A. et al. 2010. Acidity of Biomass Fast Pyrolysis Bio-oils. *Energy & Fuels*. American Chemical Society, vol. 24, ss. 6548-6554

Oasmaa, A. et al. 1011. An approach for stability measurement of wood-based fast pyrolysis bio-oils. *Energy & Fuels*. ACS Publications, vol. 25, 7, ss. 3307-3313

Fuel oil analyses

Water content 20 – 30 wt%

Acidic, pH 2 - 3

Heating value 13 - 19 MJ/kg (LHV)

Viscosity between that of light and heavy fuel oils

High ignition temperature

Density 1.15 - 1.2 kg/l

→ **Water content of the oil affects to physical properties, like heating value, density, and viscosity**



Anja Oasmaa & Cordner Peacocke

Properties and fuel use of biomass-derived fast pyrolysis liquids

A guide

<http://www.vtt.fi/inf/pdf/publications/2010/P731.pdf>



Properties and fuel use of biomass-derived fast pyrolysis liquids: a guide. VTT Publication 731. 2010 Journal of Analytical and Applied Pyrolysis., vol. 73 (2005) 2, s. 323 - 334. Energy & Fuels, 2005, vol. 19, 5, ss. 2155-2163 Environmental Progress & Sustainable Energy, 2009, 28, 3, pp. 404 - 409

Liquid fuels comparison

	FT Diesel	Low Sulphur Diesel	# 2 fuel oil	Ethanol	Butanol	Biodiesel	Vegetable oil (canola)	Tall oil	Fast pyrolysis bio-oil
Water, w t%	0	0	0	< 0.1	< 0.1	< 0.1	< 0.1	< 1	25 - 30
Density (at 15°C), kg/dm ³	0.797	0.847	0.93	0.789	0.810	0.888	0.93	0.955	1.15 - 1.2
HHV (MJ/kg)	45.5	45,6	44.2	29,8	37.3	40.2	39,7		13 - 19
LHV (MJ/kg)	43.2	42,6	41.1	27	34.4	37.5	36,9	37	11 - 17
Viscosity, cP (@20°C)	1.9-3.6	1,6	2.8-6.9	1,07	3	3.1-4.4	30		50 - 150
Flash point, °C		>62	38	13	29	>130	220	>160	Not relevant

*Fast pyrolysis bio-oils are not miscible with mineral oils or biodiesels
They are miscible with alcohols*

Conclusions

- ▼ Fast pyrolysis bio-oils are physically and chemically completely different from fossil fuels or other “bio-oils” like biodiesels or bio-alcohols and cannot be used as drop-in-fuels without appropriate upgrading
 - Fast pyrolysis bio-oils are highly polar and hence completely unmiscible with mineral oils or biodiesels
 - About 80 wt.% of the bio-oil is water-soluble
- ▼ In the EU a new chemical regulation system REACH (Registration, Evaluation and Authorisation of Chemicals) is being applied. Registration under REACH has to be made if bio-oil is produced or imported to the EU.